



# USER MANUAL

## Photovoltaic Hosting Capacity (PVHC) estimator plugin for PowerFactory

2018 edition

With the open-source PVHC estimator tool, accurately and rapidly compute the hosting capacity of your electrical network under specific solar configurations and user-defined control algorithms. Include battery systems, redefine PVHC thresholds and tailor your simulation according to your project's needs. This tool is freely available as a PowerFactory plugin (PowerFactory license not included).

MARTIN William, ALET Pierre-Jean, HUTTER Andreas  
william.martin@csem.ch, pierre-jean.alet@csem.ch, andreas.hutter@csem.ch

## Copyright

Copyright © 2018 [www.csem.ch](http://www.csem.ch), [william.martin@csem.ch](mailto:william.martin@csem.ch), [pierre-jean.alet@csem.ch](mailto:pierre-jean.alet@csem.ch), [andreas.hutter@csem.ch](mailto:andreas.hutter@csem.ch)

Permission is granted to copy, distribute and/or modify this document under the terms of the GNU Free Documentation License, Version 1.3 or any later version published by the Free Software Foundation; with no Invariant Sections, no Front-Cover Texts, and no Back-Cover Texts.

A copy of the license is in the section entitled “GNU Free Documentation License”.

## About this manual

This manual is designed to help acquaint you with the fundamentals of PVHC. This manual provides information on how to setup PVHC with PowerFactory, the methodology used to compute the PV hosting capacity and the usage of PVHC with detailed description of user inputs. This manual ends with a case example to showcase the capabilities of PVHC. Furthermore, this manual is designed with hyperlinks scattered throughout the document in order to help with navigation.

PVHC is intended for users with technical know-how in the field of power engineering and electrical network simulation with PowerFactory. An operational network modelled in PowerFactory is required, basic knowledge of coding in Python is recommended and Python scripting with PowerFactory is optional.

This manual does not serve as a Python documentation nor does it replace the user manual and all technical references of PowerFactory. In addition, this manual does not serve as a troubleshooter for simulation issues in PowerFactory nor does it interpret the results and outcomes of PVHC. Finally, PVHC will not account for real life decision making and declines all related responsibilities.

## What's new in 2018

Main new features and developments have been introduced in PVHC 2018, namely:

- It is now possible to compute the PV hosting capacity with PV systems modelled under **Active Power Input**. Until now, PVHC was only compatible with **Solar Calculation** models. Only PV systems with identical modelling can be part of a same PVHC computation.
- Objects are now class-based, namely PowerFactory objects created within PVHC. The code is therefore more readable compared to a dictionary-based approach.
- Results are output in .txt files, as opposed to Excel files of the previous PVHC version.
- Once a PVHC is executed, more information is shown, namely:
  - o A figure depicting the evolution of the number of panels incremented for each PV system (only available for **Solar Calculation** models).
  - o A logging of the algorithm is displayed, making it easier to identify the steps taken by PVHC.

## Contents

Copyright .....	1
About this manual .....	2
What's new .....	3
1 Preface .....	7
1.1 What is PVHC.....	7
1.2 What PVHC is not .....	7
2 Installation .....	8
2.1 System requirements .....	8
2.2 Setting up PVHC .....	8
2.2.1 Python interpreter .....	8
2.2.2 Path appending.....	8
2.2.3 Installing PyQt5.....	8
2.2.4 Creating a Python command .....	9
2.3 Running PVHC.....	9
3 Methodology .....	10
3.1 Basic principles .....	10
3.1.1 Increment power .....	10
3.1.2 Customizing PV installations .....	10
3.2 Algorithm setup.....	11
3.2.1 PV system ordering .....	11
3.2.2 Initial check .....	11
3.3 Failure detection and convergence .....	12
3.4 Algorithm termination .....	12
3.5 User-defined control strategies .....	13
4 Overview of PVHC.....	14
4.1 General usage.....	14
4.2 Basic options .....	14
4.3 Select PV.....	15
4.3.1 PV system tab .....	15
4.3.2 Settings tab .....	15
4.4 Select Battery .....	16
4.4.1 Battery tab .....	16
4.4.2 Settings tab .....	16

4.5	Select element.....	17
4.6	Criteria.....	17
4.6.1	Cables/lines.....	17
4.6.2	Substations .....	18
4.6.3	Fuses .....	18
4.6.4	Battery systems.....	19
4.7	Control.....	19
4.8	Miscellaneous.....	20
5	Using PVHC .....	21
5.1	Changing the quasi-dynamic simulation settings.....	21
5.1.1	Load flow.....	21
5.1.2	Time period.....	21
5.1.3	Time step size.....	22
5.2	Changing the PVHC algorithm settings.....	22
5.2.1	Panel step size.....	22
5.2.2	Panel start.....	22
5.2.3	Order of PV systems.....	22
5.3	Choosing the directory to export results .....	23
5.4	Selecting PV systems to consider in the PVHC algorithm.....	23
5.5	Modifying PV system configurations.....	23
5.5.1	Number of parallel inverters.....	23
5.5.2	Minimum number of panels per inverter .....	23
5.5.3	Maximum number of panels per inverter.....	24
5.5.4	Mounting system .....	24
5.5.5	Orientation angle.....	24
5.5.6	Tilt angle.....	24
5.5.7	Power factor .....	24
5.5.8	Latitude .....	24
5.5.9	Longitude .....	25
5.5.10	Time zone.....	25
5.6	Saving and loading PV system configurations .....	25
5.7	Selecting battery systems to consider in the PVHC algorithm .....	25
5.8	Modifying battery system configurations .....	25
5.8.1	Number of parallel units .....	25

5.8.2	Nominal apparent power .....	25
5.8.3	Power factor .....	26
5.8.4	QDSL battery system parameters .....	26
5.9	Saving and loading battery system configurations .....	26
5.10	Selecting elements for power system criteria verification .....	26
5.11	Adjusting power system criteria.....	26
5.11.1	Cable/line voltage .....	26
5.11.2	Cable/line loading .....	27
5.11.3	Substation loading .....	27
5.11.4	Substation OLTC operation .....	27
5.11.5	Fuse loading .....	27
5.11.6	Fuse current .....	27
5.11.7	Battery loading.....	27
5.12	Resetting default power system criteria .....	27
5.13	Applying user-defined control strategies .....	27
5.14	Executing a PV hosting capacity estimation.....	28
5.15	Exiting PVHC.....	29
6	Case example .....	30
6.1	Distribution network .....	30
6.2	PVHC settings .....	30
6.3	PVHC results .....	31
	References .....	33
	GNU Free Documentation License.....	34

## 1 Preface

With the rise of concerns for the environment and advances in technology for renewable energies, the number of distributed energy resources (DER) on the distribution network is increasing, namely that of photovoltaic (PV) power stations. The transmission system of today was conceived to allow bulk power to be transported from centralized power plants to end-users and did not anticipate the large deployment of competitive-priced solar power at distribution level. Thus, utility companies are experiencing an increasing number of interconnection requests [1] on their networks. Combining this with known power quality issues, such as voltage rise and reverse power flow, related to high penetration of PV generation makes the task of distribution system operators (DSO) more difficult. As a result, the DSO must go through strenuous impact studies to assess the potential adverse effects on their grid [2] before proceeding to the installation of such PV systems. Most utility companies avoid these procedures and choose to undersize their installations which leads to a very conservative deployment of PV production. As a result, the share of renewable energy sources (RES) becomes suboptimal and the grid electrical capabilities are not fully exploited.

To address this difficulty, PVHC was developed for utility companies to rapidly evaluate the current state of their grid in terms of power quality under chosen PV configurations and to estimate the total PV hosting capacity of their network. The latter is defined as “the amount of PV that can be accommodated under existing control and infrastructure configurations” [3]. PVHC takes advantage of PowerFactory to encompass the spatial and time domain of the impact of PV while considering the fully detailed model of the grid to provide an exact estimation of hosting capacity, locally and globally across the feeder.

Moreover, PVHC allows the implementation of user-defined control strategies in order to evaluate and compare their beneficial effects with respect to power quality and hosting capacity.

### 1.1 What is PVHC

PVHC is a tool that allows you to compute the PV hosting capacity of a radial low-voltage distribution network rapidly and accurately with a high level of customization according to your project’s needs. Indeed, you may redefine the thresholds for your hosting capacity, involve battery systems and include or not grid elements into the algorithm.

PVHC is programmed in Python and runs in parallel with PowerFactory. The functionalities of PowerFactory are provided in Python through a dynamic module which interfaces with the PowerFactory API thus providing Python scripts with access to a comprehensive range of data in the host application. Conversely, integrating the Python scripting language in PowerFactory allows the automation of tasks and the creation of user-defined calculation commands and methods.

When launched from within PowerFactory, PVHC takes your project’s current set-up of the grid modelled in PowerFactory and allows the configuration of various settings through a user-friendly interface, offering a seamless integration with PowerFactory.

PVHC is highly expandable and portable in a way that with proper knowledge of Python scripting with PowerFactory, PVHC’s source code can easily be modified to suit any project’s needs.

### 1.2 What PVHC is not

PVHC is not an electrical power system simulation software nor does it replace PowerFactory or any of its functionalities. Furthermore, PVHC is not a standalone program and requires an operational grid modelled in PowerFactory.

## 2 Installation

### 2.1 System requirements

PVHC requires an installation of PowerFactory with a working license containing at least the modules *Quasi-Dynamic Simulation* and *Scripting and Automation*. System requirements follow the same as PowerFactory installed on your computer.

### 2.2 Setting up PVHC

This subsection describes a step-by-step procedure for setting up and running PVHC. Before proceeding, it is highly recommended to install WinPython (<http://winpython.github.io/>) since it contains all necessary tools (Python, 3<sup>rd</sup> party Python packages, PyQt, Qt Designer, and a coding IDE called Spyder) needed for the setup below. Installing WinPython is not mandatory and the procedure described below offers alternatives for setting up PVHC, although they do not guarantee that the plugin will execute properly.

#### 2.2.1 Python interpreter

Before anything else, an installation of a Python interpreter is required (<https://www.python.org/downloads>) and its architecture (32- or 64-bit) should match that of your version of PowerFactory. Python 3.4 is recommended since it was used when developing PVHC. Moreover, this setting is also to be configured within PowerFactory (TOOLS → External Applications → Python → Version).

The used editor setting should also be entered in PowerFactory (TOOLS → External Applications → Python → Used editor), unless system default is selected. An example of editor, which was downloaded along with WinPython:

```
C:\Program Files\WinPython-64bit-3.4.4.6Qt5\Spyder.exe
```

Finally, additional Python packages imported for successfully running PVHC should normally be included in a basic Python installation.

#### 2.2.2 Path appending

This next step involves modifying a few lines of code inside `main.py` by opening the script with your recently downloaded Python editor. First, you should append the directory of the Python module for PowerFactory to your Python path. The module should correspond to the version of Python you have setup beforehand. An example used at the beginning in `main.py`, which should be modified according to your system's setup:

```
sys.path.append('C:\\Program Files\\DIgSILENT\\PowerFactory 2018 SP3')
sys.path.append('C:\\Program Files\\DIgSILENT\\PowerFactory 2018 SP3\\Python\\3.4')
```

Optionally, you can also append the directory of additional packages to your Python path. An example used inside `main.py`, which should be modified according to your system's setup:

```
sys.path.append('C:\\Program Files\\WinPython-64bit-3.4.4.6Qt5\\python-3.4.4.amd64\\Lib\\site-packages')
```

#### 2.2.3 Installing PyQt5

PVHC was developed using Qt Designer, a visual tool for making graphical user interfaces (GUI) and included in a WinPython installation. In order for Qt Designer to work, it uses a package called PyQt, which also comes along with WinPython. If you are not using WinPython, you do not need to install Qt itself, PyQt contains the Qt Designer executable and all necessary Python packages and can be downloaded here: <https://riverbankcomputing.com/software/pyqt/download5>.

With WinPython, Qt Designer and PyQt are included and you should automatically have a directory called PyQt5 inside Python's site-packages directory. An example that could be different according to your system's setup:

```
C:\Program Files\WinPython-64bit-3.4.4.6Qt5\python-3.4.4.amd64\Lib\site-packages\PyQt5
```

#### 2.2.4 Creating a Python command

A Python command object must be created in order to run PVHC from PowerFactory. To create a new Python command in PowerFactory, open the Data-Manager and create a new object via the New Object icon in the toolbar. Select DPL Command and more and then Python Script (ComPython) from the Element drop-down list. Creating a ComPython object will open up a new window allowing you to modify the recently created object. You may choose a different name for your Python command but you must link `main.py` to it. To do so, go to Script → Script file from the ComPython window then find and select `main.py` from the directory where PVHC is installed. You may then close the window or execute the script (see sub-section below).

For more information on integrating the Python scripting language in PowerFactory, refer to the user manual of PowerFactory.

### 2.3 Running PVHC

In order to run PVHC, you can either:

- Open the recently created Python command object via the Data-Manager and click on the Execute button.
- Right-click on the recently created Python command in the Data-Manager and click Execute.

If successful, the GUI of PVHC should appear. Otherwise, an error message will show up in the PowerFactory output window describing the cause of the failure.

## 3 Methodology

This section describes the methodology used to compute the PV hosting capacity in PVHC from the basic principles behind the algorithm to how user-defined control strategies are deployed.

### 3.1 Basic principles

The approach consists in simultaneously incrementing the installed power of all PV systems in the loop of the studied distribution grid, executing a [quasi-dynamic simulation](#) and a short-circuit analysis in PowerFactory, and freezing the PV systems who led to the violation of predefined thresholds of [power system criteria](#). The overall power is increased until all PV systems are frozen or until a specific amount of installed power for each system is reached, in which case the PV hosting capacity is computed.

#### 3.1.1 Increment power

Since the rated power of an installation is highly dependent on the number of installed panels, the power incremented for a PV system is equivalent to that of the peak power of one panel multiplied by the [step size](#) (in number of panels) defined by the user. This means that it is possible to study the PV hosting capacity with systems of different technologies for which the installed power will not necessarily increase at the same rate (see Figure 1). Furthermore, you can begin incrementing the power from a [starting point](#) in order to decrease the computation time of the hosting capacity. Incrementing power this way is available for PV systems set to [Solar Calculation](#).

As of 2018, it is possible to compute the PV hosting capacity by scaling the nominal power of PV systems uniformly. The approach is the same as incrementing the number of panels. The power incremented for a PV is equivalent to that of the nominal power multiplied by the [step size](#) (in terms of scaling factor) defined by the user. Finally, a [starting point](#) can be selected in order to decrease the computation time of the hosting capacity. Incrementing power this way is available for PV systems set to [Active Power Input](#).




Figure 1 How installed power is incremented (Solar Calculation)

In the example above, three different technologies of PV panels have been installed for three distinct PV systems. After the number of panels is incremented, the resulting powers of each PV system will not necessarily be the same. In order to quantify the hosting capacity purely with respect to installed power, the same panel technology may be set to every PV system.

#### 3.1.2 Customizing PV installations

The computation of a hosting capacity is designed to provide a high level of customization of PV systems. Due to possible installation constraints and depending on the model chosen for the PV plant, it is possible to adjust the [minimum](#) and

**maximum** number of installable panels for every PV system. When incrementing the overall power, these limits are covered even if they are not a multiple of the **step size**. The **starting point** is to be adjusted according to the lowest minimum number of panels among all considered PV systems (see Figure 2). PV systems are initially set to the power equivalent to the **minimum number of installable panels** if that number is greater than the **starting point**. This option is available for PV systems set to **Solar Calculation** model.




Figure 2 Customizable installations

In the example above, the power incremented will first include the green PV system alone, appending the blue then the red systems as soon as their respective minimum panels have been reached. Conversely, the power will stop incrementing for PV systems having reached their maximum panels, ending with the blue one. The blue and red PV systems are initially set to 37 and 54 panels respectively and are only incremented once the overall power reaches those values.

When computing the PV hosting capacity with PV systems set to **Active Power Input**, the power of every PV system is incremented regardless of maximum or minimum power preferences. This being said, the power of all PV systems start at a **scaling factor** and are incremented by a same **scaling factor** percentage.

## 3.2 Algorithm setup

Before incrementing the power, a few actions are carried out to prepare the algorithm and assess the feasibility of initial PV system configurations on power system criteria.

### 3.2.1 PV system ordering

When two or more PV systems are in the loop, their powers are not incremented simultaneously when a power system criteria is violated but rather one at a time. The PV systems are arranged in an **order** pre-defined by the user and calculated before the hosting capacity is performed. This procedure was chosen in order for PV systems which are the most susceptible of creating a particular failure (e.g. line overvoltage) to have their installed power incremented first.

### 3.2.2 Initial check

At the beginning of the algorithm and before the power is incremented from the **starting point**, all PV systems are set to their **minimum number of installable panels** (**Solar Calculation**) or at the **starting scaling factor** (**Active Power Input**). A quasi-dynamic simulation and a short-circuit analysis are then executed and PV systems causing a failure are turned off in the same order as previously mentioned. These PV systems will therefore not be included in the algorithm of PVHC. A workaround to this issue would be to adjust the minimum number of installable panels of faulty PV systems according to the detected failure before computing the hosting capacity or decrease the starting point for the scaling factor.

### 3.3 Failure detection and convergence

At each [panel step](#) or [scaling factor step](#), a [quasi-dynamic simulation](#) and a short-circuit analysis are executed in order to assess the impact of increasing the power of PV systems on the quality of power and on grid reliability. A list of power system criteria [4], [5] considered in PVHC's algorithm is shown below with more details of thresholds [here](#):

- Thermal limits of substations, primary, and secondary conductors.
- Power quality, quality of supply voltage.
- Impact on Load Tap Changers or OLTC.
- Fault/short-circuit currents of protection devices.

When a failure (i.e. surpassed threshold) is detected, the recently incremented PV system undergoes a bisection-like method to determine the exact installable power at a one-panel ([Solar Calculation](#)) or one-percentage scaling factor ([Active Power Input](#)) precision convergence. This procedure was chosen as a workaround to large [panel steps](#) or [scaling factor steps](#) that would have otherwise led to suboptimal solutions of hosting capacity. A flow chart illustrating this method is depicted in Figure 3.




Figure 3 Bisection method to one-panel/one-percentage precision convergence

Once the bisection method is applied, the concerned PV system is frozen, meaning it will not see its power be increased anymore even though the [maximum number of installable panels](#) has not been reached. After this, the power continues to increase for the remaining PV systems still active in the loop.

### 3.4 Algorithm termination

The PV hosting capacity is computed when every PV system has either:

- Been turned off at the initial stage of the algorithm,
- Or is frozen after applying the bisection method when a failure is detected,
- Or has reached its maximum number of installable panels ([Solar Calculation](#)).

The PVHC algorithm is thereafter terminated (see Figure 4).




Figure 4 Example of algorithm outcome for Solar Calculation models of PV systems

In the example above, dots and circles represent steps of power that have and have not been examined respectively. Crosses indicate the maximum allowable power of PV systems. This means the green PV system has been turned off from the initial stage of the algorithm, the red system has reached its maximum number of installable panels and finally the blue system underwent the bisection method due to a threshold being reached.

Furthermore, [flags triggered](#) due to detected failures as well as initial conditions are reset at the end of the algorithm.

### 3.5 User-defined control strategies

You can implement your own [control strategy](#) in the form of a Python script that will be executed after the PV hosting capacity is computed. The goal of this feature is to test and compare various control methods in order to assess their ability to increase the hosting capacity. For this task, know-how on Python scripting in PowerFactory is required.




Figure 5 Applying user-defined control strategies with PVHC

In PVHC 2018, this option is not supported for PV systems set to **Active Power Input** model.

## 4 Overview of PVHC

This section describes the graphical user interface (GUI) of PVHC with a short description of each page and tab. Hyperlinks throughout this section are available after every screenshot and send you to a more detailed description of user inputs ([section 5](#)).

### 4.1 General usage

The GUI of PVHC consists of a single window of information divided into two main parts: (I) the **page selection list** on the left and (II) the corresponding set of **user inputs of the selected page** on the right. The GUI was created to offer a seamless integration with PowerFactory in mind.




Figure 6 Main body of the graphical user interface of PVHC

### 4.2 Basic options

This page allows you to modify the type of [model for PV systems](#), the [settings of the quasi-dynamic simulation](#) that are used for the computation of the PV hosting capacity, choose input [parameters for the algorithm](#), and finally select the directory in which the simulation [results are exported](#).




Figure 7 Basic options page

- I. [PV model](#)
- II. [Load flow](#)
- III. [Time period](#)
- IV. Step size: [time step size](#), [panel step size](#)
- V. Iteration: [panel start](#), [PV order](#), [scaling factor step size](#), [scaling factor start](#)
- VI. [Export folder](#)

## 4.3 Select PV

### 4.3.1 PV system tab

This page allows you to [select \(I\) and unselect \(II\) PV systems](#) to be considered or not in the PVHC algorithm. Only electrically connected PV systems will show up on this page.




Figure 8 Select PV page, PV system tab

- I. [Selecting PV systems](#)
- II. [Unselecting PV systems](#)

### 4.3.2 Settings tab

This page allows you to [configure the PV system selected \(I\)](#). Only selected PV systems from the [PV system tab](#) can be edited. Reconfiguring PV systems in PVHC does not modify their counterpart objects in PowerFactory unless PVHC is executed.

The following settings can be set for PV systems set to **Solar Calculation** [here](#):




Figure 9 Select PV page, Settings tab, Solar calculation

- I. [Selected PV system](#)
- II. Number of: [parallel inverters](#), [minimum panels per inverter](#), [maximum panels per inverter](#)
- III. [Mounting system](#), [orientation angle](#), [tilt angle](#)
- IV. [Power factor](#)
- V. System geographical location: [latitude](#), [longitude](#), [time zone](#)
- VI. [Save](#), [load](#) and [get current PV system configurations](#)

The following settings can be set for PV systems set to **Active Power Input** [here](#):




Figure 10 Select PV page, Settings tab, Active power input

- I. [Selected PV system](#)
- II. [Power factor](#)

## 4.4 Select Battery

### 4.4.1 Battery tab

This page allows you to [select \(I\) and unselect \(II\) battery systems](#) to be considered or not in the PVHC algorithm. Only electrically connected battery systems will show up on this page. In this version of PVHC, only quasi-dynamic simulation models (QDSL) of battery systems are supported and will appear on this page. Of course, you can create your own battery system model in PowerFactory and have it operate in parallel with PVHC like any other PowerFactory object. For more details on QDSL models, see the PowerFactory user manual.




Figure 11 Select battery page, Battery tab

- I. [Selecting battery systems](#)
- II. [Unselecting battery systems](#)

### 4.4.2 Settings tab

This page allows you to [configure the battery system selected \(I\)](#). Only selected battery systems from the [Battery tab](#) can be edited. Reconfiguring battery systems in PVHC does not modify their counterpart objects in PowerFactory unless PVHC is executed.




Figure 12 Select battery page, Settings tab

- I. [Selected battery system](#)
- II. General parameters: [number of parallel units](#), [nominal apparent power](#), [power factor](#)
- III. [QDSL battery system parameters](#)
- IV. [Save](#) and [load](#) battery system configurations

## 4.5 Select element

This page allows you to [select \(I\) and unselect \(II\) PowerFactory elements](#) (cables/lines, substations, fuses) that will respectively be included and dismissed in the PVHC process. Verification of [power system criteria](#) will be done for **selected elements** whereas **unselected elements** will be dismissed.




Figure 13 Select element page

- I. [Selecting elements](#)
- II. [Unselecting elements](#)

## 4.6 Criteria

This pages allows you to [adjust various power system criteria](#) that are verified for the [selected elements](#) during the computation of the PV hosting capacity. **Power system criteria** for [unselected elements](#) are dismissed.

### 4.6.1 Cables/lines

This page allows you to modify the **power system criteria** that are verified for the [selected cables/lines](#) during the computation of the PV hosting capacity.




Figure 14 Criteria page, Line tab

- I. [Cable/line voltage](#) criteria
- II. [Cable/line loading](#) criteria
- III. [Reset](#) to default values

#### 4.6.2 Substations

This page allows you to modify the **power system criteria** that are verified for the [selected substations](#) during the computation of the PV hosting capacity.




Figure 15 Criteria page, Transformer tab

- I. [Substation loading](#) criteria
- II. [Substation OLTC operation](#) criteria
- III. [Reset](#) to default values

#### 4.6.3 Fuses

This page allows you to modify the **power system criteria** that are verified for the [selected fuses](#) during the computation of the PV hosting capacity.




Figure 16 Criteria page, Fuse tab

- I. [Fuse loading](#) criteria
- II. [Fuse current](#) criteria
- III. [Reset](#) to default values

#### 4.6.4 Battery systems

This page allows you to modify the **power system criteria** that are verified for the [selected battery systems](#) during the computation of the PV hosting capacity.




Figure 17 Criteria page, Battery tab

- I. [Battery system loading](#) criteria
- II. [Reset](#) to default values

#### 4.7 Control

On the Control page you have the possibility to include your own Python-scripted control strategy that will be executed at the end of every consecutive PV hosting capacity. For more details on the PVHC algorithm combined with user-defined control, see [also](#).




Figure 18 Control page

- I. [Apply control, select control script](#)

## 4.8 Miscellaneous

On every page, PVHC can be executed or closed via the buttons below.




Figure 19 Miscellaneous buttons

- I. [Execute, close, and cancel](#)

## 5 Using PVHC

This section describes all user inputs available via the GUI of PVHC. Hyperlinks for every parameter and variable described below are available throughout this section and send you to the appropriate screenshot of where these inputs can be entered in the plugin ([section 4](#)).

### 5.1 Changing the quasi-dynamic simulation settings

You have the possibility to change the settings of the quasi-dynamic simulation that is used for the computation of the PV hosting capacity of your study case in PowerFactory.

#### 5.1.1 PV model

Just like in PowerFactory, you have the possibility to select the model for PV systems. Available models are:

- **Active Power Input:** the active power value can be specified directly. The power for this type of model is incremented by increasing the scaling factor.
- **Solar Calculation Mode:** the active power is calculated according to meteorological data, plant positioning, and time. See the technical reference for more details. The power for this type of model is incremented by increasing the number of panels of the PV system.

This setting can be change [here](#).

#### 5.1.2 Load flow

A quasi-dynamic simulation consists of a sequence of **load flow** calculations solved at every time step from the start to the end of the simulation period. The calculation methods currently available are:

- **AC Load Flow, balanced, positive sequence:** for single-phase positive sequence network representations, valid for balanced symmetrical networks. The simulation time with this type of method is relatively fast.
- **AC Load Flow, unbalanced, 3 Phase (ABC):** for multi-phase network representations, valid for analyzing unbalanced 3-phase systems, e.g. introduced by unbalance loads. The simulation time with this type of method is the slowest.
- **DC Load Flow (linear):** calculation method based on a set of linear equations, where the voltage angles of the buses are strongly related to the active power flow through cables and lines. The simulation time with this type of method is the fastest.

When PVHC is launched, the default calculation method is automatically set to **AC Load Flow, unbalance, 3 Phase (ABC)**, regardless of the method used for your study case in PowerFactory. Thus, closing PVHC will not save the **load flow** setting for latter sessions. You are free to select the desired calculation method, which will then be applied for the estimation of the hosting capacity. **DC Load Flow (linear)** is currently not supported in PVHC. For more details on **power flow** calculation methods, see the PowerFactory user manual.

This setting can be changed [here](#).

#### 5.1.3 Time period

Just like in PowerFactory, you have the possibility to modify the **start** and **end** period for your quasi-dynamic simulations. PVHC does not check if the entered timeframe of simulation is covered by that of your project nor does it align itself with the Time Characteristics of your project. For more details on time dependent quantities, see the PowerFactory user manual.

When PVHC is launched, the **start** and **end** period are taken directly from the last quasi-dynamic simulation executed in PowerFactory. A shorter period will result in shorter simulation times and vice versa.

This setting can be changed [here](#).

#### 5.1.4 Time step size

The **step size** for quasi-dynamic simulations can be redefined. When PVHC is launched, a 10-minute resolution is selected by default to comply with some of EN 50160 criteria. A larger step size will result in shorter simulation times and vice versa.

This setting can be changed [here](#).

### 5.2 Changing the PVHC algorithm settings

The algorithm behind the computation of the PV hosting capacity accepts input variables that may improve total simulation time or alter final results in terms of installed solar power.

#### 5.2.1 Panel step size

You can modify the **incremented number of panels** for PV systems at each iteration of the algorithm. For more details on this parameter, see [also](#). The default value for the **panel step size** is 1. Preferably, you should increase this value to speed up execution time. This option is only available for [PV models](#) set to **Solar Calculation Mode**.

This setting can be changed [here](#).

#### 5.2.2 Panel start

The algorithm of PVHC starts incrementing the number of panels installed for PV systems at **panel start**. For more details on this parameter, see [also](#). The default value for **panel start** is 1 but should be increased depending on how familiar you are with your grid in order to decrease execution time. For example, if you know from previous simulations the lowest minimum number of panels for your PV systems, then **panel start** may be set to that value. Furthermore, setting **panel start** too low may trigger under-voltages measured on cables/lines and thus terminate PVHC prematurely. This scenario typically occurs when high loads and low distributed generation are installed along the feeder of your distribution grid. This option is only available for [PV models](#) set to **Solar Calculation Mode**.

This setting can be changed [here](#).

#### 5.2.3 Order of PV systems

The increment of panels is iteratively done for one PV system at a time. The order in which these PV systems are incremented is arranged according to your selection of **order of PV systems**:

- **Voltage deviation:** PV systems are arranged in decreasing order of the measured maximum over-voltage at their PCC. PV systems creating the highest over-voltage are thus placed in first position of iteration.
- **Distance from substation:** PV systems are arranged in decreasing order of their distance from the feeding substation. PV systems located the furthest from the substation are thus placed in first position of iteration.
- **Maximum loading:** PV systems are arranged in decreasing order of the measured maximum loading of the cable/line connecting the PCC to the rest of the network. PV systems creating the highest maximum cable/line loading are thus placed in first position of iteration.
- **Random:** PV systems are arranged in random order.

Prior knowledge of the main weakness of your network may influence the **order of PV systems**. A judicious choice of this parameter may potentially give best results in terms of PV hosting capacity. The default value for the **order of PV systems** is set to **voltage deviation**. For more details on this parameter, see [also](#). This option is only available for [PV models](#) set to **Solar Calculation Mode**.

This setting can be changed [here](#).

#### 5.2.4 Scaling factor step size

You can modify the **incremented scaling factor (%)** for PV systems at each iteration of the algorithm. For more details on this parameters, see [also](#). The default value for the **scaling factor step size** is 10%. Preferable, you should increase this value to speed up execution time. This option is only available for [PV models](#) set to **Active Power Input**.

This setting can be changed [here](#).

#### 5.2.5 Scaling factor start

The algorithm of PVHC starts incrementing the scaling factor of PV systems at **scaling factor start**. For more details on this parameter, see [also](#). The default value for **scaling factor start** is 100%, but should be increase depending on how familiar you are with your grid in order to decrease execution time. For example, if you know from previous simulations the lowest minimum scaling factor for your PV systems, then **scaling factor start** may be set to that value. Furthermore, setting **scaling factor start** too low may trigger under-voltages measured on cables/lines and thus terminate PVHC prematurely. This scenarios typically occurs when high loads and low distribution generation are installed along the feeder of your distribution grid. This option is only available for [PV models](#) set to **Active Power Input**.

This setting can be change [here](#).

### 5.3 Choosing the directory to export results

All results of PVHC are exported in a folder located in the directory chosen in **export folder**. You are free to choose any existing directory on your system but the default value is set to one directory above that of the PVHC executable files in a folder named **PVHC\_results**. Inside the latter, another folder is created every time PVHC is executed with the name made up of the **date and time** of execution and of the **project and study case name**. Finally, this folder stores the PVHC results (in .csv format).

This setting can be changed [here](#).

### 5.4 Selecting PV systems to consider in the PVHC algorithm

**Selected PV systems** will be considered in the PVHC algorithm whereas **unselected PV systems** will automatically be turned off (thus generating zero power) after executing PVHC. If you need a PV system to be operational but not processed in the algorithm, you can either:

- Set the [minimum number of panels](#) equal to the [maximum number of panels](#).
- Get the [current PV system configuration](#) directly from PowerFactory.

**Selecting and unselecting PV systems** can be done by either double-clicking the name of the PV system in the appropriate lists or using the buttons available [here](#).

Only PV systems operating under the model chosen in the [basic options](#) can be selected for the computation of the PV hosting capacity.

### 5.5 Modifying PV system configurations

You may **modify the configuration of PV systems** before computing the PV hosting capacity. Do to so, [select a PV system in the appropriate list](#) and the set of **configurable parameters** will show up for that PV system. For more details on these parameters, see the PowerFactory technical reference for PV systems.

For PV systems set to **Active Power Input**, only the [power factor](#) can be configured.

#### 5.5.1 Number of parallel inverters

The first time PVHC is launched, the **number of parallel inverters** displayed for the selected PV system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

#### 5.5.2 Minimum number of panels per inverter

The default value for the **minimum number of panels** for the selected PV system is 1. For more details on this parameter, see [also](#). Once edited, the equivalent minimum power of the PV system is displayed and is computed as follows:

$$P_{min}^{PV} = N_{min}^{panel} * P^{panel} [W] \quad (1)$$

This parameter can be configured [here](#).

### 5.5.3 Maximum number of panels per inverter

The default value for the **maximum number of panels** for the selected PV system is 100. For more details on this parameter, see [also](#). Once edited, the equivalent maximum power of the PV system is displayed and is computed as follows:

$$P_{max}^{PV} = N_{max}^{panel} * P^{panel} [W] \quad (2)$$

This parameter can be configured [here](#).

### 5.5.4 Mounting system

The first time PVHC is launched, the **mounting system** displayed for the selected PV system is taken from the counterpart object in PowerFactory. The following **mounting systems** can be selected in PVHC and correspond to those in PowerFactory:

- **Fixed/Stationary:** you must specify the orientation and tilt angles.
- **Dual Axis Tracking System:** the orientation and tilt angles will follow the solar altitude and azimuth angles accordingly.
- **Horizontal Single Axis Tracking System:** you must specify the orientation angle. The tilt angle will follow the solar altitude angle accordingly.
- **Vertical Single Axis Tracking System:** you must specify the tilt angle. The orientation angle will follow the azimuth angle accordingly.

This parameter can be configured [here](#).

### 5.5.5 Orientation angle

The first time PVHC is launched, the **orientation angle** displayed for the selected PV system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.5.6 Tilt angle

The first time PVHC is launched, the **tilt angle** displayed for the selected PV system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.5.7 Power factor

The first time PVHC is launched, the **power factor** displayed for the selected PV system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.5.8 Latitude

The first time PVHC is launched, the **latitude** displayed for the selected PV system is taken from the terminal at which the counterpart PV system is connected in PowerFactory.

This parameter can be configured [here](#).

### 5.5.9 Longitude

The first time PVHC is launched, the **longitude** displayed for the selected PV system is taken from the terminal at which the counterpart PV system is connected in PowerFactory.

This parameter can be configured [here](#).

### 5.5.10 Time zone

The first time PVHC is launched, the **time zone** displayed for the selected PV system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

## 5.6 Saving and loading PV system configurations

You can conveniently **save** and **load** PV systems to save time when experimenting with different configurations or when a PV system configuration is needed in another project or study case. All parameters are saved or loaded except for the [minimum](#) and [maximum](#) number of panels, which are considered more as algorithm parameters than PV system configurable variables. By default, configuration files are stored in the same directory as the PVHC executable files in a folder named *settings\_pv*. Finally, the type of these configuration files are *.xml* format.

Moreover, it is possible to **get the current configuration** of the selected PV system directly from the counterpart object in PowerFactory. In addition, this function replaces the [minimum](#) and [maximum](#) number of panels of the selected PV system by the number of panels per inverter of the counterpart object in PowerFactory.

These functions are only available for PV systems set to **Solar Calculation** mode.

These functions are accessible [here](#).

## 5.7 Selecting battery systems to consider in the PVHC algorithm

**Selected battery systems** will be considered in the PVHC algorithm whereas **unselected battery systems** will automatically be turned off (thus providing no storage functions) after executing PVHC. This also means that power system criteria for **selected battery systems** are verified and conversely dismissed for **unselected battery systems**.

**Selecting and unselecting battery systems** can be done by either double-clicking the name of the battery system in the appropriate lists or using the buttons available [here](#).

## 5.8 Modifying battery system configurations

You may **modify the configuration of battery systems** before computing the PV hosting capacity. Do to so, [select a battery system in the appropriate list](#) and the set of **configurable parameters** will show up for that battery system. **Configurable parameters** specific to QDSL modeled battery systems will also appear. For more details on these parameters, see the PowerFactory user manual.

### 5.8.1 Number of parallel units

The first time PVHC is launched, the **number of parallel units** displayed for the selected battery system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.8.2 Nominal apparent power

The first time PVHC is launched, the **nominal apparent power** displayed for the selected battery system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.8.3 Power factor

The first time PVHC is launched, the **power factor** displayed for the selected battery system is taken from the counterpart object in PowerFactory.

This parameter can be configured [here](#).

### 5.8.4 QDSL battery system parameters

**QDSL battery system parameters** displayed for the selected battery system are imported directly from the counterpart object in PowerFactory, regardless of the values edited in a previous PVHC session (unless PVHC is executed, in which case the parameters will be modified inside PowerFactory).

These parameters can be configured [here](#).

## 5.9 Saving and loading battery system configurations

You can conveniently **save** and **load** battery systems to save time when experimenting with different configurations or when a battery system configuration is needed in another project or study case. By default, configuration files are stored in the same directory as the PVHC executable files in a folder named *settings\_batt*. Finally, the type of these configuration files are *.xml* format. An error message box appears if PVHC failed to load a battery system configuration (e.g., if the loaded QDSL model does not match that of the selected battery system).

These functions are accessible [here](#).

## 5.10 Selecting elements for power system criteria verification

**Selected elements** will be subject to the verification of power system criteria while computing the PV hosting capacity whereas **unselected elements** will be dismissed (but not turned off as opposed to PV and battery systems).

**Selecting and unselecting elements** can be done by either double-clicking the name of the elements in the appropriate lists or using the buttons available [here](#).

## 5.11 Adjusting power system criteria

The selected elements will be subject to the verification of their corresponding power system criteria whenever a quasi-dynamic simulation or a short-circuit analysis is executed. Each criterion holds a flag which triggers once its threshold is exceeded. The various criteria for each element as well as their default parameters are described below.

### 5.11.1 Cable/line voltage

Flags for cable/line voltage are triggered whenever:

- The over-voltage exceeds a certain maximum threshold (p.u.) for a defined period of time (%).
- The under-voltage is inferior to a certain minimum threshold (p.u.) for a defined period of time (%).

The default values for the maximum and minimum voltage limits are respectively:

- 1.10 p.u. for 95% of the simulation period.
- 0.90 p.u. for 95% of the simulation period.

These default thresholds correspond to those of 50160 standards, ensuring the quality of supply voltage in a distribution network. This parameter is triggered when performing a quasi-dynamic simulation.

These criteria can be adjusted [here](#).

### 5.11.2 Cable/line loading

Flags for cable/line loading are triggered whenever the maximum loading exceeds a defined maximum threshold (%), which corresponds to the maximum ampacity limit. The default value for the maximum loading is 100%. This parameter is triggered when performing a quasi-dynamic simulation.

This criteria can be adjusted [here](#).

### 5.11.3 Substation loading

Flags for substation loading are triggered whenever the maximum loading exceeds a defined maximum threshold (%), which corresponds to the maximum thermal limit. The default value for the maximum loading is 100%. This parameter is triggered when performing a quasi-dynamic simulation.

This criteria can be adjusted [here](#).

### 5.11.4 Substation OLTC operation

Flags for substation OLTC operation are triggered whenever the number of OLTC tap changes per day exceeds a value equal to the number of operations before maintenance divided by the number of days until the next maintenance of the OLTC. The default values are 100'000 operations before maintenances every 7 years, which is equivalent to a maximum of 39 taps per day. This parameter is triggered when performing a quasi-dynamic simulation.

This criteria can be adjusted [here](#).

### 5.11.5 Fuse loading

Flags for fuse loading are triggered whenever the maximum loading exceeds a defined maximum threshold (%), which corresponds to the maximum thermal limit. The default value for the maximum loading is 100%. This parameter is triggered when performing a short-circuit analysis.

This criteria can be adjusted [here](#).

### 5.11.6 Fuse current

Flags for fuse current are triggered whenever the maximum breaking and short-circuit currents exceed their respective nominal ratings (%). The default value is 100%. This parameter is triggered when performing a short-circuit analysis.

These criteria can be adjusted [here](#).

### 5.11.7 Battery loading

Flags for battery system loading are triggered whenever the maximum loading exceeds a defined maximum threshold (%), which corresponds to the maximum thermal limit. The default value for the maximum loading is 100%. This parameter is triggered when performing a quasi-dynamic simulation.

This criteria can be adjusted [here](#).

## 5.12 Resetting default power system criteria

You can reset the default power system criteria individually for each type of element. This means that resetting the cable/line default criteria won't reset those for substations.

This can be done by clicking the appropriate **Reset** button of the corresponding page [here](#).

## 5.13 Applying user-defined control strategies

By ticking the control box [here](#), a field box will appear for you to select you own Python script containing the **control strategy** you wish to implement. The function inside `main.py` **opens**, **reads**, and **executes** the control script with the input arguments

contained inside a Python dictionary (Search for `open(control_options['script_path']).read()` in `main.py`). For more details on the `exec` function, see the Python documentation. Currently, the available input arguments are the following:

- **app**: corresponds to the PowerFactory application module created inside `main.py`.
- **basic\_options**: contains the settings selected for your simulation and algorithm environment. These settings can be modified on this [page](#).
- **selected\_pv**: corresponds to a list containing the name of the PV systems selected [here](#).
- **selected\_batt**: corresponds to a list containing the name of battery systems selected [here](#).
- **selected\_line**: corresponds to a list containing the name of cables/lines selected [here](#).
- **selected\_tran2**: corresponds to a list containing the name of substations selected [here](#).
- **selected\_fuse**: corresponds to a list containing the name of the fuses selected [here](#).
- **criteria\_line**: contains the thresholds for the power system criteria regarding cables/lines. These parameters can be modified [here](#).
- **criteria\_tran2**: contains the thresholds for the power system criteria regarding substations. These parameters can be modified [here](#).
- **criteria\_fuse**: contains the thresholds for the power system criteria regarding fuses. These parameters can be modified [here](#).
- **criteria\_batt**: contains the thresholds for the power system criteria regarding battery systems. These parameters can be modified [here](#).

Inside the Python script dedicated to your control strategy, input arguments of your main function should follow the same order as that of passed arguments in `main.py`. All functions and methods specific to the Python and PowerFactory environment obey and are executed as they would normally do in `main.py`.

#### 5.14 Executing a PV hosting capacity estimation.

Executing a PV hosting capacity estimation via the button [here](#) will perform the actions in the following order:

- I. Create a list containing the name of selected elements (PV systems, battery systems, cables/lines, substations, and fuses) for later use.
- II. Save the [simulation and algorithm settings](#), [power system criteria](#), and [control options](#) in corresponding classes for later use.
- III. Set up the PVHC algorithm, see [also](#).
- IV. Proceed to the computation of the PV hosting capacity, see [also](#).
- V. Export PVHC results and plot in PowerFactory.
- VI. Execute the selected [control strategy](#), if chosen to.
- VII. Repeat steps IV-VI according to Figure 5, if the control option is enabled.
- VIII. Reset initial conditions and flags.

Moreover, a dialogue box will appear displaying the status of the algorithm, the time elapsed, a figure detailing the evolution of panels incremented (only for **Solar Calculation**), and a log file describing the steps and decisions taken by the algorithm. Tinkering with settings and options in the background while PVHC is performing is not advised. A Cancel button is available for this purpose and will interrupt any current task, except for step VI above. Once the control script is executed, the dialogue box disappears and gives way to your control strategy to be carried out. This means your control strategy cannot be interrupted unless explicitly coded in your script. At the end of the latter, step IV is repeated with the dialogue box showing up again.

Furthermore, a PV hosting capacity computation cannot be performed if the following conditions are not met (an error message box will appear):

- At least one [PV system must be selected](#).
- The [panel start](#) parameter must be lower than the lowest [minimum number of panels](#) among your PV systems.
- At least [one object must be selected](#) for a power system criteria verification.

- A control script must be selected if the [control option](#) is enabled.
- The [start](#) must be earlier than the [end time](#) of the simulation.
- Any PV system model does not correspond to that selected among [PV models](#).
- The [control option](#) is enabled and [PV model](#) is set to **Active Power Input** (not supported in PVHC 2018)

Once the algorithm is finished, user settings entered in PVHC will have modified their counterpart object in PowerFactory, namely PV systems, battery systems, and simulation settings.

Executing PVHC can be done [here](#).

## 5.15 Exiting PVHC

There are two ways of exiting the plugin: the **Close** and **Cancel** button [here](#).

**Closing** PVHC will save all current inputs from PV system configurations to current page and tab, except the following parameters which are by default when launching PVHC:

- The [load flow](#) type.
- The [start](#) and [end time](#) as well as the [time step](#) of quasi-dynamic simulations.
- The QDSL model parameters for the [battery system configuration](#) (unless PVHC is executed in which case the counterpart object in PowerFactory is modified). A workaround was created which consists in [loading a battery system configuration](#) previously saved.

The closed PVHC session is thus saved and stored in *settings.xml* located in a folder called *tmp* in the same directory as the executable files. The session is loaded when PVHC is launched again, unless four hours have passed or the project and study case have changed since the last PVHC session, in which case default values are loaded instead.

On the other hand, exiting PVHC using the **Cancel** button will not save the current session. Launching PVHC after cancelling will either load default values or a previously saved PVHC session.

## 6 Case example

This section presents a case example showcasing the capabilities of PVHC and the content of the results file generated at the end of the algorithm.

### 6.1 Distribution network

The case example was performed on the CIGRE benchmark low-voltage microgrid network [6] where all RES have been replaced by PV systems. The grid operates at 50 Hz and has a radial layout like usual LV networks, with a feeder departing from the secondary side of the substation and prosumers connected anywhere along the feeder and its branches. The feeder consists of 26 households divided into five groups located at the end of various branches. Finally, a PV system is installed at each of these groups of dwellings, where we assume a fixed mounting system corresponding to typical modern installations on residential roofs. The main lines consist of overhead AI cables with Cu service cables connecting the groups of households.

Measurements of global irradiance and temperature were extracted from a local weather station at a 10 minute resolution. Daily consumption profiles of various home appliances were generating using BEHAVSIM [7], a behavior simulator using stochastic parameters. These profiles were created for each of the 26 households and consist of dishwashers, washing machines, lighting, fridges, and electric boilers.




Figure 21 CIGRE benchmark low-voltage microgrid network

### 6.2 PVHC settings

The unbalanced AC load flow option was chosen for a quasi-dynamic simulation of 1 week at a time step of 10 minutes. Panels are iterated at a step of 10 with the overall power starting at 120 panels. PV systems are ordered according to voltage deviation since it is known from successive simulations that service cables at the end of branches are vulnerable to over-voltages. All PV systems have been selected to take part in the computation of the PV hosting capacity and have the following configurations:




Figure 22 Case example PV configurations

No battery systems have been included into the algorithm. The service cables connecting the rest of the feeder to the PV systems as well as the first line departing from the secondary of the substation have been considered for the verification of power system criteria. The latter has been set to agree with EN 50160 standards with thermal rating thresholds at 100 %, which correspond to default parameters in PVHC.

### 6.3 PVHC results

Simulations were performed on a computer equipped with a 2.50 GHz Intel® Core™ i5-7200U processor and 16.00 GB of RAM. The computation of the PV hosting capacity took 7 minutes and 38 seconds.




Figure 23 PV hosting capacity results

The blue PV systems have reached their maximum installable number of panels (220), whereas all other PV systems underwent the bisection method because an overvoltage of 1.10 p.u. for more than 5 % of the simulated week was detected at the PCC of PV3 (see Figure 24). PV systems PV0, PV2, and PV4 have respectively reached 252, 250, and 255 panels. The total hosting capacity was computed at 237.56 kVA.

These data were extracted from the .csv file generated at the end of the algorithm where all information of simulation settings, chosen thresholds, and PV system configurations are saved. The file includes hosting capacity results as well as the list of flags triggered or not for every selected network element. For this case example (see Figure 24), an overvoltage was detected due to incrementing the power of PV4, then PV2, and finally PV0. Plot of




Figure 24 PCC voltage near PV3

61	SC_3	Max. voltage fail	[False]				
62		Min. votlage fail	[False]				
63		Max. loading fail	[False]				
64	SC_4	Max. voltage fail	[True, 'PV_System_4', 'PV_System_2', 'PV_System_0']				

Figure 25 Failures detected and causes

## References

- [1] 'Solar Market Insight Report 2013 Year in Review', *SEIA*. [Online]. Available: <http://www.seia.org/research-resources/solar-market-insight-report-2013-year-review>. [Accessed: 06-Feb-2017].
- [2] R. J. Broderick, J. E. Quiroz, M. J. Reno, A. Ellis, J. Smith, and R. Dugan, 'Time Series Power Flow Analysis for Distribution Connected PV Generation', *Sandia Natl. Lab. SAND2013-0537*, 2013.
- [3] M. Rylander, L. Rogers, and J. Smith, 'Distribution Feeder Hosting Capacity: What Matters When Planning for DER?' EPRI, Apr-2015.
- [4] J. Smith and M. Rylander, 'Distribution Planning with DER: Distribution System-Wide Impact Assessment Methods', presented at the Integrating PV in Distribution Grids: Solutions and Technologies Workshop, Golden, Colorado, USA, 22-Oct-2015.
- [5] P. Q. A. Guide, 'Voltage Disturbances', *Stand. EN*, vol. 50160, 2005.
- [6] S. Papathanassiou, N. Hatziargyriou, K. Strunz, and others, 'A benchmark low voltage microgrid network', in *Proceedings of the CIGRE symposium: power systems with dispersed generation*, 2005, pp. 1–8.
- [7] G. Basso, P. Ferrez, D. Gabioud, and P. Roduit, 'An Extensible Simulator for Dynamic Control of Residential Area: Case Study on Heating Control', in *2015 Euromicro Conference on Digital System Design (DSD)*, 2015, pp. 486–493.

## GNU Free Documentation License

Version 1.3, 3 November 2008

Copyright © 2000, 2001, 2002, 2007, 2008 Free Software Foundation, Inc. <<https://fsf.org/>>

Everyone is permitted to copy and distribute verbatim copies of this license document, but changing it is not allowed.

### 0. PREAMBLE

The purpose of this License is to make a manual, textbook, or other functional and useful document "free" in the sense of freedom: to assure everyone the effective freedom to copy and redistribute it, with or without modifying it, either commercially or noncommercially. Secondly, this License preserves for the author and publisher a way to get credit for their work, while not being considered responsible for modifications made by others.

This License is a kind of "copyleft", which means that derivative works of the document must themselves be free in the same sense. It complements the GNU General Public License, which is a copyleft license designed for free software.

We have designed this License in order to use it for manuals for free software, because free software needs free documentation: a free program should come with manuals providing the same freedoms that the software does. But this License is not limited to software manuals; it can be used for any textual work, regardless of subject matter or whether it is published as a printed book. We recommend this License principally for works whose purpose is instruction or reference.

### 1. APPLICABILITY AND DEFINITIONS

This License applies to any manual or other work, in any medium, that contains a notice placed by the copyright holder saying it can be distributed under the terms of this License. Such a notice grants a world-wide, royalty-free license, unlimited in duration, to use that work under the conditions stated herein. The "Document", below, refers to any such manual or work. Any member of the public is a licensee, and is addressed as "you". You accept the license if you copy, modify or distribute the work in a way requiring permission under copyright law.

A "Modified Version" of the Document means any work containing the Document or a portion of it, either copied verbatim, or with modifications and/or translated into another language.

A "Secondary Section" is a named appendix or a front-matter section of the Document that deals exclusively with the relationship of the publishers or authors of the Document to the Document's overall subject (or to related matters) and contains nothing that could fall directly within that overall subject. (Thus, if the Document is in part a textbook of mathematics, a Secondary Section may not explain any mathematics.) The relationship could be a matter of historical connection with the subject or with related matters, or of legal, commercial, philosophical, ethical or political position regarding them.

The "Invariant Sections" are certain Secondary Sections whose titles are designated, as being those of Invariant Sections, in the notice that says that the Document is released under this License. If a section does not fit the above definition of Secondary then it is not allowed to be designated as Invariant. The Document may contain zero Invariant Sections. If the Document does not identify any Invariant Sections then there are none.

The "Cover Texts" are certain short passages of text that are listed, as Front-Cover Texts or Back-Cover Texts, in the notice that says that the Document is released under this License. A Front-Cover Text may be at most 5 words, and a Back-Cover Text may be at most 25 words.

A "Transparent" copy of the Document means a machine-readable copy, represented in a format whose specification is available to the general public, that is suitable for revising the document straightforwardly with generic text editors or (for images composed of pixels) generic paint programs or (for drawings) some widely available drawing editor, and that is suitable for input to text formatters or for automatic translation to a variety of formats suitable for input to text formatters. A copy made in an otherwise Transparent file format whose markup, or absence of markup, has been arranged to thwart or discourage subsequent modification by readers is not Transparent. An image format is not Transparent if used for any substantial amount of text. A copy that is not "Transparent" is called "Opaque".

Examples of suitable formats for Transparent copies include plain ASCII without markup, Texinfo input format, LaTeX input format, SGML or XML using a publicly available DTD, and standard-conforming simple HTML, PostScript or PDF designed for human modification. Examples of transparent image formats include PNG, XCF and JPG. Opaque formats include proprietary formats that can be read and edited only by proprietary word processors, SGML or XML for which the DTD and/or processing tools are not generally available, and the machine-generated HTML, PostScript or PDF produced by some word processors for output purposes only.

The "Title Page" means, for a printed book, the title page itself, plus such following pages as are needed to hold, legibly, the material this License requires to appear in the title page. For works in formats which do not have any title page as such, "Title Page" means the text near the most prominent appearance of the work's title, preceding the beginning of the body of the text.

The "publisher" means any person or entity that distributes copies of the Document to the public.

A section "Entitled XYZ" means a named subunit of the Document whose title either is precisely XYZ or contains XYZ in parentheses following text that translates XYZ in another language. (Here XYZ stands for a specific section name mentioned below, such as "Acknowledgements", "Dedications", "Endorsements", or "History".) To "Preserve the Title" of such a section when you modify the Document means that it remains a section "Entitled XYZ" according to this definition.

The Document may include Warranty Disclaimers next to the notice which states that this License applies to the Document. These Warranty Disclaimers are considered to be included by reference in this License, but only as regards disclaiming warranties: any other implication that these Warranty Disclaimers may have is void and has no effect on the meaning of this License.

## 2. VERBATIM COPYING

You may copy and distribute the Document in any medium, either commercially or noncommercially, provided that this License, the copyright notices, and the license notice saying this License applies to the Document are reproduced in all copies, and that you add no other conditions whatsoever to those of this License. You may not use technical measures to obstruct or control the reading or further copying of the copies you make or distribute. However, you may accept compensation in exchange for copies. If you distribute a large enough number of copies you must also follow the conditions in section 3.

You may also lend copies, under the same conditions stated above, and you may publicly display copies.

## 3. COPYING IN QUANTITY

If you publish printed copies (or copies in media that commonly have printed covers) of the Document, numbering more than 100, and the Document's license notice requires Cover Texts, you must enclose the copies in covers that carry, clearly and legibly, all these Cover Texts: Front-Cover Texts on the front cover, and Back-Cover Texts on the back cover. Both covers must also clearly and legibly identify you as the publisher of these copies. The front cover must present the full title with all words of the title equally prominent and visible. You may add other material on the covers in addition. Copying with changes limited to the covers, as long as they preserve the title of the Document and satisfy these conditions, can be treated as verbatim copying in other respects.

If the required texts for either cover are too voluminous to fit legibly, you should put the first ones listed (as many as fit reasonably) on the actual cover, and continue the rest onto adjacent pages.

If you publish or distribute Opaque copies of the Document numbering more than 100, you must either include a machine-readable Transparent copy along with each Opaque copy, or state in or with each Opaque copy a computer-network location from which the general network-using public has access to download using public-standard network protocols a complete Transparent copy of the Document, free of added material. If you use the latter option, you must take reasonably prudent steps, when you begin distribution of Opaque copies in quantity, to ensure that this Transparent copy will remain thus accessible at the stated location until at least one year after the last time you distribute an Opaque copy (directly or through your agents or retailers) of that edition to the public.

It is requested, but not required, that you contact the authors of the Document well before redistributing any large number of copies, to give them a chance to provide you with an updated version of the Document.

#### 4. MODIFICATIONS

You may copy and distribute a Modified Version of the Document under the conditions of sections 2 and 3 above, provided that you release the Modified Version under precisely this License, with the Modified Version filling the role of the Document, thus licensing distribution and modification of the Modified Version to whoever possesses a copy of it. In addition, you must do these things in the Modified Version:

- A. Use in the Title Page (and on the covers, if any) a title distinct from that of the Document, and from those of previous versions (which should, if there were any, be listed in the History section of the Document). You may use the same title as a previous version if the original publisher of that version gives permission.
- B. List on the Title Page, as authors, one or more persons or entities responsible for authorship of the modifications in the Modified Version, together with at least five of the principal authors of the Document (all of its principal authors, if it has fewer than five), unless they release you from this requirement.
- C. State on the Title page the name of the publisher of the Modified Version, as the publisher.
- D. Preserve all the copyright notices of the Document.
- E. Add an appropriate copyright notice for your modifications adjacent to the other copyright notices.
- F. Include, immediately after the copyright notices, a license notice giving the public permission to use the Modified Version under the terms of this License, in the form shown in the Addendum below.
- G. Preserve in that license notice the full lists of Invariant Sections and required Cover Texts given in the Document's license notice.
- H. Include an unaltered copy of this License.
- I. Preserve the section Entitled "History", Preserve its Title, and add to it an item stating at least the title, year, new authors, and publisher of the Modified Version as given on the Title Page. If there is no section Entitled "History" in the Document, create one stating the title, year, authors, and publisher of the Document as given on its Title Page, then add an item describing the Modified Version as stated in the previous sentence.
- J. Preserve the network location, if any, given in the Document for public access to a Transparent copy of the Document, and likewise the network locations given in the Document for previous versions it was based on. These may be placed in the "History" section. You may omit a network location for a work that was published at least four years before the Document itself, or if the original publisher of the version it refers to gives permission.
- K. For any section Entitled "Acknowledgements" or "Dedications", Preserve the Title of the section, and preserve in the section all the substance and tone of each of the contributor acknowledgements and/or dedications given therein.
- L. Preserve all the Invariant Sections of the Document, unaltered in their text and in their titles. Section numbers or the equivalent are not considered part of the section titles.
- M. Delete any section Entitled "Endorsements". Such a section may not be included in the Modified Version.
- N. Do not retitle any existing section to be Entitled "Endorsements" or to conflict in title with any Invariant Section.
- O. Preserve any Warranty Disclaimers.

If the Modified Version includes new front-matter sections or appendices that qualify as Secondary Sections and contain no material copied from the Document, you may at your option designate some or all of these sections as invariant. To do this, add their titles to the list of Invariant Sections in the Modified Version's license notice. These titles must be distinct from any other section titles.

You may add a section Entitled "Endorsements", provided it contains nothing but endorsements of your Modified Version by various parties—for example, statements of peer review or that the text has been approved by an organization as the authoritative definition of a standard.

You may add a passage of up to five words as a Front-Cover Text, and a passage of up to 25 words as a Back-Cover Text, to the end of the list of Cover Texts in the Modified Version. Only one passage of Front-Cover Text and one of Back-Cover Text may be added by (or through arrangements made by) any one entity. If the Document already includes a cover text for the same cover, previously added by you or by arrangement made by the same entity you are acting on behalf of, you may not add another; but you may replace the old one, on explicit permission from the previous publisher that added the old one.

The author(s) and publisher(s) of the Document do not by this License give permission to use their names for publicity for or to assert or imply endorsement of any Modified Version.

## 5. COMBINING DOCUMENTS

You may combine the Document with other documents released under this License, under the terms defined in section 4 above for modified versions, provided that you include in the combination all of the Invariant Sections of all of the original documents, unmodified, and list them all as Invariant Sections of your combined work in its license notice, and that you preserve all their Warranty Disclaimers.

The combined work need only contain one copy of this License, and multiple identical Invariant Sections may be replaced with a single copy. If there are multiple Invariant Sections with the same name but different contents, make the title of each such section unique by adding at the end of it, in parentheses, the name of the original author or publisher of that section if known, or else a unique number. Make the same adjustment to the section titles in the list of Invariant Sections in the license notice of the combined work.

In the combination, you must combine any sections Entitled "History" in the various original documents, forming one section Entitled "History"; likewise combine any sections Entitled "Acknowledgements", and any sections Entitled "Dedications". You must delete all sections Entitled "Endorsements".

## 6. COLLECTIONS OF DOCUMENTS

You may make a collection consisting of the Document and other documents released under this License, and replace the individual copies of this License in the various documents with a single copy that is included in the collection, provided that you follow the rules of this License for verbatim copying of each of the documents in all other respects.

You may extract a single document from such a collection, and distribute it individually under this License, provided you insert a copy of this License into the extracted document, and follow this License in all other respects regarding verbatim copying of that document.

## 7. AGGREGATION WITH INDEPENDENT WORKS

A compilation of the Document or its derivatives with other separate and independent documents or works, in or on a volume of a storage or distribution medium, is called an "aggregate" if the copyright resulting from the compilation is not used to limit the legal rights of the compilation's users beyond what the individual works permit. When the Document is included in an aggregate, this License does not apply to the other works in the aggregate which are not themselves derivative works of the Document.

If the Cover Text requirement of section 3 is applicable to these copies of the Document, then if the Document is less than one half of the entire aggregate, the Document's Cover Texts may be placed on covers that bracket the Document within the aggregate, or the electronic equivalent of covers if the Document is in electronic form. Otherwise they must appear on printed covers that bracket the whole aggregate.

## 8. TRANSLATION

Translation is considered a kind of modification, so you may distribute translations of the Document under the terms of section 4. Replacing Invariant Sections with translations requires special permission from their copyright holders, but you may include translations of some or all Invariant Sections in addition to the original versions of these Invariant Sections. You

may include a translation of this License, and all the license notices in the Document, and any Warranty Disclaimers, provided that you also include the original English version of this License and the original versions of those notices and disclaimers. In case of a disagreement between the translation and the original version of this License or a notice or disclaimer, the original version will prevail.

If a section in the Document is Entitled "Acknowledgements", "Dedications", or "History", the requirement (section 4) to Preserve its Title (section 1) will typically require changing the actual title.

## 9. TERMINATION

You may not copy, modify, sublicense, or distribute the Document except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense, or distribute it is void, and will automatically terminate your rights under this License.

However, if you cease all violation of this License, then your license from a particular copyright holder is reinstated (a) provisionally, unless and until the copyright holder explicitly and finally terminates your license, and (b) permanently, if the copyright holder fails to notify you of the violation by some reasonable means prior to 60 days after the cessation.

Moreover, your license from a particular copyright holder is reinstated permanently if the copyright holder notifies you of the violation by some reasonable means, this is the first time you have received notice of violation of this License (for any work) from that copyright holder, and you cure the violation prior to 30 days after your receipt of the notice.

Termination of your rights under this section does not terminate the licenses of parties who have received copies or rights from you under this License. If your rights have been terminated and not permanently reinstated, receipt of a copy of some or all of the same material does not give you any rights to use it.

## 10. FUTURE REVISIONS OF THIS LICENSE

The Free Software Foundation may publish new, revised versions of the GNU Free Documentation License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. See <https://www.gnu.org/licenses/>.

Each version of the License is given a distinguishing version number. If the Document specifies that a particular numbered version of this License "or any later version" applies to it, you have the option of following the terms and conditions either of that specified version or of any later version that has been published (not as a draft) by the Free Software Foundation. If the Document does not specify a version number of this License, you may choose any version ever published (not as a draft) by the Free Software Foundation. If the Document specifies that a proxy can decide which future versions of this License can be used, that proxy's public statement of acceptance of a version permanently authorizes you to choose that version for the Document.

## 11. RELICENSING

"Massive Multiauthor Collaboration Site" (or "MMC Site") means any World Wide Web server that publishes copyrightable works and also provides prominent facilities for anybody to edit those works. A public wiki that anybody can edit is an example of such a server. A "Massive Multiauthor Collaboration" (or "MMC") contained in the site means any set of copyrightable works thus published on the MMC site.

"CC-BY-SA" means the Creative Commons Attribution-Share Alike 3.0 license published by Creative Commons Corporation, a not-for-profit corporation with a principal place of business in San Francisco, California, as well as future copyleft versions of that license published by that same organization.

"Incorporate" means to publish or republish a Document, in whole or in part, as part of another Document.

An MMC is "eligible for relicensing" if it is licensed under this License, and if all works that were first published under this License somewhere other than this MMC, and subsequently incorporated in whole or in part into the MMC, (1) had no cover texts or invariant sections, and (2) were thus incorporated prior to November 1, 2008.

The operator of an MMC Site may republish an MMC contained in the site under CC-BY-SA on the same site at any time before August 1, 2009, provided the MMC is eligible for relicensing.